

Wiring of Your New Ventless Hood For Peerless CE62PESC/CE231PESC Ovens

Please have a qualified electrician to hook up your CE62PESC or CE231PESC. Attached is the diagram of the contactor assembly that is required to run your double stack electric oven with your new Peerless Ventless hood.

The service for the entire unit goes to the electrical box on the hood so your units works as certified for Ventless use.

For the unit to operate, all six filters must be in place and the kill switches depressed. For a diagram on which filter goes in first, second and last, see the diagram in these pages.

To turn the unit(s) back on:

- 1) Turn on the toggle switch located on the side of the control box near the back of the hood.
- 2) Press the black reset button also located on the control panel and hold for 5 seconds.
- 3) Turn the toggle located on the front of the C131P/C231P to the "On" position.

Follow instructions located in the Peerless printed manual for additional operation instructions.

PEERLESS MAXIMIZER PRODUCTS